

Winslow Cuff

Project B2187

Designer: Kat Silvia

This cuff features a Lapis Lazuli gemstone wire wrapped on to faux leather. This dimensional brass cuff is the perfect structure for this bead embroidered bracelet.

What You'll Need

Create Recklessly, Symphony Faux Leather 10 x 2 Inch Strip, 1 Piece, Fudge Brown

SKU: XCR-1328

Project uses 1 piece



Lapis Lazuli Grade A Long Oval Gemstone Beads 14.5x30mm (2)

SKU: SPL-40

Project uses 1 piece



Toho Demi Round Seed Beads, Thin 11/0 (2.2mm) Size, 7.8 Grams, 615 Matte Iris Purple

SKU: DRH-0023

Project uses 1 Tube



Beadsmith Ultra Suede For Beading Foundation And Cabochon Work 8.5x4.25 In. - Coffee Bean

SKU: XCR-4372

Project uses 1 piece



Artistic Wire, Copper Craft Wire 24 Gauge Thick, 10 Yard Spool, Tarnish Resistant Brass

SKU: WCR-2433

Project uses 1 piece



NYMO Nylon Beading Thread Size D for Delica Beads Brown 64YD (58 Meters)

SKU: XCR-8919

Project uses 1 piece



Flat Cuff Bracelet Base, with Four Bends 38mm (1.5) Wide, 1 Piece, Raw Brass

SKU: JB-2826

Project uses 1 piece



Recommended Tools:

[XTL-0058] BeadSmith Metal Hole Punch Pliers For Sheet Metal - 1.25mm, [XTL-0074]

Eurotool Nylon Jaw Pliers Chain Nose- For Scratch-Free Wire Work, [XTL-5520] Lindstrom EX

Series - Flush Cutter Pliers 5 Inches Long, [XTL-5519] Lindstrom EX Series - Chain Nose

Jewelry Pliers 5.75 Inches Long, [XTL-0812] Create Recklessly, Poly Punching Cutting &

Tooling Board with Ruler, [XTL-0811] Create Recklessly, Rotary Cutter for Leather Fabric &

Paper 45mm, [XTL-3006] Beadsmith English Beading Needles Size 12 (4 Needles),

[XTL-5700] Fiskars 5 Precision Tip Scissors - Super Sharp

Instructions

1. Begin by cutting the length of faux leather so it is 1 5/8 inch wide and 6 5/8 inches. It is better to err on the side of safety when cutting, you can always trim it later.
2. Cut a length of ultra suede that is 1 5/8 inch wide and 6 5/8 inches.
3. In the very center of the strip of faux leather, wire wrap the Lapis Lazuli gemstone so it will sit on the center section of the cuff. Please watch our video: [How to Wire Wrap a Gemstone onto Faux Leather](#). From what you learned in the video, mark off the back of the faux leather with one hole on the top and bottom and then three holes on each side. Cut off about 20 inches of wire and wire wrap the gemstone on to the faux leather.
4. Line up the faux leather on the outer side of the cuff and the ultra suede on the inner side of the cuff. You will then fuse them together by making a bead embroidered edge using the nymo beading thread and the Toho demi round seed beads. As you work you will need to tie off and add new thread.
5. Go all the way around the cuff, trimming if necessary, and when you have come back to the beginning, tie off and weave in the tail.
6. All done!