

# **Spirit Messenger Necklace**

## **Project N8068**

Alexandra Smith

Across cultures, the feather is considered a symbol of freedom and high honor. This native-inspired necklace features a kumihimo beaded focal, finished with antiqued copper findings by TierraCast. Textured double link cable chain lends rustic balance to the design.

#### What You'll Need

Genuine Metal Seed Beads 8/0 Copper 38 Grams

SKU: BMS-0801 Project uses 1 tube



Toho Round Seed Beads 8/0 508 'Higher Metallic Iris Olivine' 8 Gram Tube

SKU: JSH-0111 Project uses 1 tube



TierraCast Pewter Pendant, Native Feather 72mm, 1 Piece, Antiqued Copper Plated

SKU: PNT-009

Project uses 1 piece



SKU: FCO-9386

Project uses 1 piece



Cord End, Roped Dome 12.5mm, Fits 5mm Cord, Antiqued Copper, 2 Pieces, By TierraCast

SKU: FCR-4260

Project uses 2 pieces



Super-Lon (S-Lon) Cord - Size #18 Twisted Nylon - Gray (77 Yard Spool)

SKU: XCR-4613 Project uses 1 spool



Antiqued Copper Plated Textured Double Link Cable Chain, 5mm, by the Foot

SKU: CHA-9852 Project uses 24 inches



TierraCast Copper Plated Pewter Large Leaf Toggle Clasp 16.5mm (1)

SKU: FCL-7038

Project uses 1 piece



Antiqued Copper Plated Open Jump Rings 6mm 20 Gauge (50)

SKU: FJR-3093

Project uses 5 pieces



E6000 Industrial Strength Glue Adhesive (0.18 fl oz)

SKU: XTL-1054 Project uses 1 tube









#### Recommended Tools:

[XTL-6095] Beadsmith Lightweight Kumihimo Round Disc Disk For Japanese Braiding and Cording 35mm Hole, [XTL-6108] No Tangle Flexible Plastic Thread Bobbins For Kumihimo Or Macrame 2 1/2 Inch (8 Pack), [XTL-6063] Gator Weight For Kumihimo Braiding - 1.6 Ounces (1), [XTL-5700] Fiskars 5 Precision Tip Scissors - Super Sharp, [XTL-5600] Sharp Flush Cutter Pliers - For Cutting Beading Wire, 1 Piece, [XTL-0020] Baby Wubbers Quality Fine Chain Nose Jeweller's Pliers, [XTL-0023] Baby Wubbers Quality Fine Bent Chain Nose Jeweller's Pliers, [XTL-9920] Beadaholique Bead Mat, 12.5x9.25 Inches, 1 Piece

### Instructions

These instructions will make a 32 inch necklace. To modify the size, adjust the length of chain used on either side respectively. You will also need a scrap of wire or toothpick to complete this project.

- 1. If you are new to kumihimo, begin by watching our video on how to braid beaded kumihimo.
- 2. Based on the technique shown in the video, cut eight 3 foot lengths of gray S-lon cord and tie them together with an overhand knot at one end.
- 3. String 33 Toho 8/0 olivine seed beads onto four of the strands.
- 4. String 33 copper 8/0 copper seed beads onto the four remaining strands.
- 5. Wind your threads onto the bobbins as shown in the video.
- 6. Arrange the threads in your kumihimo disc in the following order: Two strands of olivine seed beads on either side of the 32 dot at the top, two strands of olivine seed beads on either side of the 16 dot at the bottom, two strands of copper seed beads on either side of the 24 dot at the left, and two strands of copper seed beads on either side of the 8 dot at the right. Attach your weight to the knot after you have positioned your cords.
- 7. Begin braiding as shown in the video. Braid about 1 inch of cord before you begin adding the beads.
- 8. Continue braiding until you have added all of your beads. Then continue braiding 1 inch of cord without beads, same as you did at the beginning.
- 9. Carefully remove the braid from the disc, trim the bobbins off, and tie an overhand knot.
- 10. To add your bail and feather charm: Slide on your bail and position it at the center of your beaded braid. If necessary, gently twist the bail to fit it over the beads. Then use pliers to open a 6mm jump ring and slide on the loop of your bail. Also slide on the loop of your feather charm. Close the jump ring.
- 11. To attach your cord ends: Please watch the end of this video. Using the finishing technique shown in the video, size one end of your braid to fit inside your cord end. To do this, take a length of S-lon cord and tie an overhand knot over the braided portion of the end of the Kumihimo without the beads. Tie a second overhand knot to secure. Then take the tails and wrap around the braided portion to bulk up the tail end. When it is the right bulk to fit in the well of the clasp, tie another knot to secure and trim the ends with your scissors. Using a toothpick or scrap of wire, add a dab of E6000 into the well of one cord end. Place one end of the braid into the cord end. Repeat this step to attach a cord end on the other side of your braid. Let dry for at least 20 minutes.
- 12. To attach your chain: Use cutters to cut two 12 inch lengths of double link cable chain. Open a jump ring and slide on the loop on one cord ends, and attach it to the end link of one 12 inch chain. Close the jump ring. In this same manner, attach your second length of chain to your other cord end.
- 13. To attach your clasp: Open another jump ring and attach one side of your toggle clasp to one end of the chain. Close the jump ring. Repeat this step to attach the other side of your clasp on the opposite side of your necklace. All Done!