

Bohemia Bracelet

Project B156
Designer: Andrea Morici

This Boho-chic bracelet evokes a free spirited lady with an easy and eclectic, devil-may-care style. The color palette is a warm, antique-ish mix of rich reds, earthy browns, and a touch of turquoise; all in the form of various Czech glass.



What You'll Need

Soft Flex Best Beading Wire Antique Brass .014 Inch - 30 Ft.



SKU: XCR-5005
Project uses 1 foot

Economy Antiqued Brass Crimp Beads 2mm x 1.5mm (50)



SKU: FCR-1260
Project uses 2 pieces

Antiqued Brass Crimp Bead Covers 3mm (50)



SKU: FCR-1090
Project uses 2 pieces

Brass Oxide Finish Pewter Heirloom Toggle Clasp 14.7mm (1)



SKU: FCL-7800
Project uses 1 piece

Antiqued Brass Head Pins 2 Inches Long/22 Gauge (X50)



SKU: FHP-6312
Project uses 7 pieces

Czech Glass Druk Round Beads 6mm Hurricane Glass Green Orange Swirl (50)



SKU: BCP-76209
Project uses 14 pieces

Czech Glass Fluted Cathedral Beads 9mm Opaque Red/Picasso (12 Beads)



SKU: BCP-39201
Project uses 2 pieces

Czech Glass Fluted Cathedral Beads 9mm Jet Black/Bronze (12 Beads)



SKU: BCP-39210
Project uses 2 pieces

Czech Glass Fluted Cathedral Beads 9mm Opaque Turquoise/Picasso (12 Beads)



SKU: BCP-39200
Project uses 2 pieces

Czech Glass Beads Three Petal Flower 12mm Opaque Red/Picasso (12)



SKU: BCP-92144
Project uses 7 pieces

Brass Oxide Finish Lead-Free Pewter Disk Heishi Spacer Beads 3mm (50)



SKU: BMB-5750
Project uses 14 pieces

Miyuki Delica Seed Beads 10/0 Matte Metallic Green/Pink DBM0380 8 GR



SKU: DBM-0380
Project uses 7 pieces

Specialized Tools

Xuron Sharp Flush Cutter Pliers - Wire/Soft Flex



SKU: XTL-5600

Beadsmith Jewelry Fine Round Nose Micro Pliers



SKU: XTL-5514

Double Notch Crimping Pliers - Works on 2mm And 3mm Crimps



SKU: XTL-5230

Instructions:

1. Begin by threading a delica and a Czech glass flower onto a headpin. Make a wrapped wire loop on the headpin, just above the flower, and trim off excess wire. Create six more of these flower danglers, for a total of seven, and set them aside.
2. Use your flush cutters to cut a length of beading wire which is approximately one foot long. Secure one end of the beading wire with a Bead Stopper.
3. Onto your wire, thread the following: a brass oxide heishi spacer, a 6mm Czech druk bead, a flower dangle, a 6mm Czech druk bead, a brass oxide heishi spacer, and a turquoise fluted cathedral bead.
4. Repeat this stringing sequence five more times, ending each sequence with a different colored fluted cathedral bead. e.g. first sequence ended with turquoise, second sequence ends with red, third: black, repeat.
5. After you have strung the last sequence, string an additional brass oxide heishi spacer, a 6mm Czech druk bead, a flower dangle, a 6mm Czech druk bead, and another brass oxide heishi spacer.
6. Onto the end of your strand thread a brass crimp bead, but do not crimp it yet.
7. Thread the end of the strand through the loop on one half of the toggle clasp, back through the crimp bead and several consecutive beads, pull the wire snug, and crimp the crimp bead.
8. Remove the Bead Stopper from the other end of the bracelet and repeat the previous step here.
9. Place a crimp bead cover over each of the crimp beads and gently squeeze them closed.
10. Trim off excess beading wire.