

Lake Havasu Bracelet

Project B2026

Designer: Kat Silvia

The antique copper plated pewter pieces from TierraCast combined with the turquoise ultra suede gives this bracelet a subtle global marketplace feel.

What You'll Need

Beadsmith Turquoise Faux Leather Suede Beading Cord 9Ft (3 Yd) Spool

SKU: XCR-43119

Project uses 1 spool



Real Copper Foldover 3mm Cord Ends For Leather (x50)

SKU: FCR-1436

Project uses 12 pieces



Genuine Antiqued Copper Open Jump Rings 5mm 19 Gauge (50)

SKU: FJR-5002

Project uses 16 pieces



TierraCast Antiqued Copper Plated 16mm Spiral Ring Connector Link (2)

SKU: FCO-3143

Project uses 6 pieces



TierraCast Antiqued Copper Plated Lead-Free Pewter 6-Hole Strand Reducer 7.5x19.5mm (2)

SKU: FCO-9230

Project uses 2 pieces



TierraCast Antiqued Copper Plated Pewter Spiral Toggle Clasp Set 16.5mm (1)

SKU: FCL-7112

Project uses 1 piece



Recommended Tools:

[XTL-5260] Beadsmith Fold Over Crimping Pliers For Leather & Suede Findings, [XTL-5700]

Fiskars 5 Precision Tip Scissors - Super Sharp, [XTL-5514] Beadsmith Jewelry Fine Round

Nose Micro Pliers, [XTL-5511] Beadsmith Jeweller's Micro Pliers Chain Nose Flat Nose



Instructions

This design will give you a bracelet that measures 7".

1. Cut 6 pieces of ultra suede cord; 5 1/2 inches long.
2. Onto both ends of each piece of the suede cord, use the fold over cord ends to finish the ends. How to use Fold Over Crimping Pliers.
3. Lay out the cords. Taking one strand reducer, line up each cord to each corresponding hole. Open a jump ring and attach the first cord end to the first hole of the strand reducer. Close the jump ring. Repeat this for each cord, but only on this side. Do not attach the other side just yet.

4. Now to add the connector links to the bracelet, lay out your cords so they are in order. For our purposes we will label them 1, 2 and so forth from the bottom to the top.
5. Place one connector link on to cords 1, 2, and 3. Slide down.
6. Place one connector link on to cords 3, 4, and 5. Slide down.
7. Place one connector link on to cords 2, 3, and 4. Slide down.
8. Place one connector link on to cords 4, 5, and 6. Slide down.
9. Place one connector link on to cords 1, 2, and 3. Slide down.
10. Place one connector link on to cords 3, 4, and 5. Slide down.
11. You will now attach the other ends of cords to the other strand reducer with the jump rings, in the same order as the other side. To the end of this strand reducer you will use three jump rings to form a chain. Onto the last jump ring, attach the toggle bar of the clasp and close the jump ring.
12. Going back to the first side, open one jump ring and attach the circle of the toggle clasp to the strand reducer loop. Close the jump ring.