

# **Tori Bracelet**

### Project B2220

Kat Silvia

Show off your glam rock side with this strip of Ultra Suede adorned with Swarovski Crystal Framed Flatbacks.

## What You'll Need

Swarovski Crystal, 2078/H Framed Round Flatback Rhinestone 7.8mm, 4 Pieces, Jet Hematite / Silver

SKU: SWCR-1154 Project uses 4 pieces



Swarovski Crystal, 2078/H Framed Round Flatback Rhinestone 5.2mm, 12 Pieces, Jet Hematite / Silver

SKU: SWCR-1149

Project uses 9 pieces



Swarovski Crystal, 2078/H Framed Round Flatback Rhinestone 4.5mm, 24 Pieces, Jet Hematite / Silver

SKU: SWCR-1144 Project uses 14 pieces



Beadsmith Ultra Suede For Beading Foundation And Cabochon Work 8.5x4.25 Inches Black Onyx

SKU: XCR-4380 Project uses 1 piece



Silver Plated Ribbon Pinch Crimps Cord Ends - 19.5mm (4)

SKU: FCR-1403

Project uses 2 pieces

1

Necklace Extender, 4x3mm Curb Chain with Drop and Clasp, 10 Pieces, Silver Plated SKU: AXC-0101 Project uses 1 piece

Silver Plated Open Jump Rings 4mm 21 Gauge Thick (100)

SKU: FJR-5140 Project uses 2 pieces 1 Gauge Th

#### Recommended Tools:

[XTL-5514] Beadsmith Jewelry Fine Round Nose Micro Pliers, [XTL-5511] Beadsmith Jeweller's Micro Pliers Chain Nose Flat Nose, [XTL-1522] BeadSmith Cordless Vacuum HotFX Applicator Tool, for Hotfix Crystals with Spotlight, [XTL-5700] Fiskars 5 Precision Tip Scissors - Super Sharp







### Instructions

These instructions will give you a bracelet that is 6.5" long with a chain extender to give you up to 8 inches in length. To adjust the size simply modify the length of ultra suede used.



- 1. Begin by cutting a strip of ultra suede 3/4 of an inch wide and 6 inches long.
- 2. Attach a ribbon crimp to each end.

3. Using your Hot FX tool, you will now place the Swarovski rhinestones to the ultra suede. You can follow along with my placement (see photo) or design your own. I suggest placing them before using the tool to secure them.

4. Open one jump ring and attach it to the loop of the lobster clasp and to one loop of the ribbon crimp. Close the jump ring.

5. Open another jump ring and attach it to the last link in the chain extender and to one loop of the second ribbon crimp. Close the jump ring.