

One Fine Day Bracelet

Project B2409

Kat Silvia

Make a statement with this sparkling stunner featuring Swarovski crystal pearls and rondelle beads.

What You'll Need

Swarovski Crystal, #5810 Round Faux Pearl Beads 12mm, 4 Pieces, Pearlescent White

SKU: SWP-1276

Project uses 12 pieces



Final Sale - Swarovski Crystal, #77512 BeCharmed Rondelle 4.5mm Large Hole Beads 12mm, 2 Pcs, Aquamarine

SKU: SWBB-5096

Project uses 11 pieces



Silver Plated Wire & Thread Protectors .024 Inch Loops (50)

SKU: FCR-4165

Project uses 2 pieces



Silver Plated Open Jump Rings 5mm 20 Gauge (x100)

SKU: FJR-5150

Project uses 6 pieces



Silver Plated Curved Lobster Clasps 15mm (10)

SKU: FCL-2522

Project uses 1 piece



Swarovski Crystal, Rhodium Plated Channel Charm, 7mm, 8 Pieces, Sapphire

SKU: SWFA-1011

Project uses 1 piece



Shiny Silver Tone Crimp Bead Covers 4mm (x144)

SKU: FCR-1054

Project uses 2 pieces



Crimp Beads, Tube 2x2mm, 100 Pieces, Silver Plated

SKU: FCR-9009

Project uses 2 pieces



Beadalon Wire Standard Bright 49 Strand .018 Inch / 30Ft

SKU: XCR-64813

Project uses 10 Inches



Recommended Tools:

[XTL-5511] Beadsmith Jeweller's Micro Pliers Chain Nose Flat Nose, [XTL-5600] Sharp Flush

Cutter Pliers - For Cutting Beading Wire, 1 Piece, [XTL-5608] Xuron 4 In 1 Crimping Pliers -

Works On 1, 2 And 3mm Crimps!, [XTL-3000] Bead Stopper- Stop Beads Sliding Off Stringing

Material



Instructions

This bracelet measures 6.5 inches. For a longer or shorter bracelet simply adjust the number of beads strung respectively. Note: For a longer bracelet you may need to purchase additional beads.

1. Begin by cutting off 10 inches of wire. Place a bead stopper at one end of the wire. String on one Swarovski pearl and alternate with one rondelle. Repeat 10 times and end with one more Swarovski pearl.
2. String on one crimp tube. Thread the wire up and over one wire protector and before threading it back down through the crimp tube, slide on one lobster clasp. After threading the wire through the crimp tube, crimp it and add a crimp cover.
3. Move to the other side of this strand, remove the bead stopper and repeat the above step without the lobster clasp.
4. Open one jump ring and attach it to the wire protector. Close the jump ring.
5. To make a chain extender, simply add jump rings to this jump ring in a chain. Once you have your desired length, attach one final jump ring with the crystal charm.