

## Fleur de Lis Bracelet

### Project B600

Designer: Julie Bean

From the blue and white toile looking backing to the silver fleur de lis', this bracelet is oh so very French. Imagine walking along the Avenue de Champs d'Elyse or strolling the right bank while wearing this charming piece.



## What You'll Need

Nunn Design Antiqued Silver Tone Collage Bracelet Lrg 18mm Rounds



SKU: AXC-9459  
Project uses 1 piece

Antiqued Silver Plated Fleur De Lis Charms 14mm (4)



SKU: PND-5404  
Project uses 5 pieces

Nunn Design Collage Sheet Green/Navy Floral For Scrapbook - Fits Patera Patera



SKU: XTL-9518  
Project uses 1 piece

E6000 Industrial Strength Glue Adhesive (0.18 fl oz)



SKU: XTL-1054  
Project uses 1 piece



## Specialized Tools

Fiskars 5 Precision Tip Scissors - Super Sharp



SKU: XTL-5700

Xuron Sharp Flush Cutter Pliers - Wire/Soft Flex



SKU: XTL-5600

Ice Resin Kit for filling Bezel Settings



SKU: PKIT-0001

## Instructions:

1. To begin this project, take your pre-made bracelet and place a piece of scrap paper on top of one of the 18mm circle sections. holding the bracelet and the circle between your thumb and index finger, press them together so that you make an imprint of the circle on the paper. Cut out the circle. Use this circle as a template to trace around on the backside of your blue and white paper. Trace and cut out 5 circles, if you need to cut them down slightly to fit into you bracelet settings, do so at this time.
2. Take one cut-out blue and white circle and spread Nunn glue on the backside. Place into one of your bracelet settings and press into place. Repeat with your other 4 circles. Let Dry. Once dry, apply a coat of Nunn Sealant over the top. Let dry.
3. Pull out 5 fleur de lis' and cut off the charm loops at the top using your flush cutters. On the back side of each, place a dab of E6000 glue. Place each fleur de lis in the center of your bracelet settings and let dry completely.
4. Mix and pour your resin. Remove any air bubbles with a micro torch. Wait 3 days before wearing so your resin can completely cure.
5. C'est Fini!