

Napoli Bracelet

Project B688

Designer: Julie Bean

Featuring fashionable resort colors of rhinestone cup chain, this bangle bracelet is a 'must have' accessory this season.

What You'll Need

Nunn Design Antiqued 24kt Gold Plated Round Channel Bangle Bracelet - 2 3/4 Inch

SKU: JB-2661

Project uses 1 piece



Czech Glass White Pearl On Brass Cup Chain PP24 (By The Foot)

SKU: CHA-10103

Project uses 9 inches



Czech Crystal Brass Rhinestone Cup Chain 18PP Coral Orange (By The Foot)

SKU: CHA-10117

Project uses 9 inches



Czech Crystal Brass Rhinestone Cup Chain 18PP Turquoise (By The Foot)

SKU: CHA-10121

Project uses 9 inches



G S Hypo Cement Precise Applicator Essential!

SKU: XTL-1001

Project uses 1 tube



Recommended Tools:

[XTL-5600] Xuron Sharp Flush Cutter Pliers - Wire/Soft Flex



Instructions

Note: You will use approximately 9 inches of each of the rhinestone cup chains for this project, however, do not precut your chains, start with the entire 12 inches of each.

- Using the fine tip applicator of the GS HypoCement, draw a line of glue 2 inches long inside the channel of your bangle, up near the top edge. Rest into this glue one end of the 18pp coral rhinestone cup chain and then start laying the length of chain into the glue (flat backside against the glue). Let dry for a few minutes. Starting where you left off, draw another 2 inch glue line. Lay the chain into this glue line and let dry. Work your way all the way around your bangle repeating this process.
- When you get to within 1/2 inch of where your chain beginning and end will meet, gauge how many more chain links will fit on your bangle and snip off the excess with flush cutters. Create your last glue line and place your remaining chain links into it. Let dry.
- Repeat the previous two steps, first with your 24pp pearl cup chain (which should be placed in the middle of the bangle) and then with your 18pp turquoise cup chain which will be the last row of chain and rest up against the edge of the bangle. See photo for reference.
- Let dry and then you are done!