

# **Celestial Charm Bracelet**

## Project B8052

Alexandra Smith

Swarovski Crystal stars and channel charms twinkle amidst delicate charm chain accents in this ethereal charm bracelet. Luminous crystal elements contrast with mixed metals for a balance of light and shadow.

## What You'll Need

Charm Chain, Star 7mm, Antiqued Silver Plated, Cut to Order, by the Inch

SKU: CHX-2012 Project uses 2 inches



Charm Chain, Hoop Circles 5mm, Matte Gold Plated, Cut to Order, by the Inch

SKU: CHX-2014 Project uses 2 inches



Matte Gold Plated Rolo Chain, 3.7mm, by the Foot

SKU: CHA-9952 Project uses 6 inches



Swarovski Crystal, #6715 Star Pendant 14mm, 2 Pieces, Crystal AB

SKU: SWC-002





Swarovski Crystal, #6715 Star Pendant 14mm, 2 Pieces, Crystal Golden Shadow

SKU: SWC-003

Project uses 3 pieces



Swarovski Crystal, Rhodium Plated Channel Charm, 7mm, 8 Pieces, Sapphire

SKU: SWFA-1011 Project uses 4 pieces



22K Gold Plated Open Jump Rings 4mm 20 Gauge 22k Gold Plated (100)

SKU: FJR-3914

Project uses 26 pieces



22K Gold Plated Open Jump Rings 6mm 20 Gauge (20)

SKU: FJR-5220

Project uses 5 pieces



TierraCast Maker's Collection, Craftsman Toggle Clasp Set, 22K Gold Plated

SKU: FCL-1755 Project uses 1 piece



#### **Recommended Tools:**

[XTL-0023] Baby Wubbers Quality Fine Bent Chain Nose Jeweller's Pliers, [XTL-0020] Baby Wubbers Quality Fine Chain Nose Jeweller's Pliers, [XTL-5600] Sharp Flush Cutter Pliers - For Cutting Beading Wire, 1 Piece, [XTL-0328] Third Hand Tool For Jewelry Repair, Includes







Alligator Clips / Magnifier / Cast Iron Base

### Instructions

These instructions will make a 6.5 inch bracelet. For a longer or shorter bracelet, choose your desired length of rolo chain. For related tips on how to utilize the third hand tool in the assembly of this design, please watch this video.

- 1. Begin by preparing your chains as follows: Use flush cutters to cut apart ten links of star charm chain by clipping the jump rings attaching the charms. Set aside 20 silver star links. Repeat this process to set aside 20 gold circle links. Then cut 6 inches of rolo chain.
- 2. If you are using a third hand tool, secure the end links of your rolo chain into the clips of the tool.
- 3. To assemble the first half of your charm bracelet: Open a 6mm jump ring and slide on the hole of one yellow Swarovski Crystal star. Also slide on the centermost link of your rolo chain. Close the jump ring.
- 4. Open a 4mm jump ring and slide on two antiqued silver star links. Also slide on the link of rolo chain two links over from the yellow crystal star you attached in step one. Close the jump ring. Repeat this process to hang two gold circle links two links over from your dangling silver stars.
- 5. Open another 4mm jump ring and slide on the loop of one blue Swarovski Crystal channel charm. Also slide on the link of rolo chain two links over from your gold circle links. Close the jump ring.
- 6. Repeat step 4 to attach two more of each of the silver stars and gold rings.
- 7. Now repeat steps 3 through 6 to continue the pattern, this time adding a white Swarovski Crystal star.
- 8. Repeat steps 3 and 4 to add one more yellow Swarovski Crystal star and two of each of the silver stars and gold rings.
- 9. To assemble the second half of your charm bracelet: Repeat steps 3 through 8, working in the reverse to attach charms to the other side of your bracelet.
- 10. To attach your clasp: Open a jump ring and slide on one end link of one of your rolo chain. Also slide on the loop of your toggle clasp. Close the jump ring.
- 11. Open another jump ring and slide on the other end link of your rolo chain. Also slide on the loop of your toggle bar. Close the jump ring. All Done!