

Divine Deco Earrings

Project E3065

Designer: Karlin Jones

Make these sleek drop earrings by combining SWAROVSKI ELEMENTS Artemis Cone beads in Jet and rondelle beads in Crystal. The outcome is an art deco-inspired accessory that will sparkle beautifully as it

What You'll Need

Nunn Design Antiqued Gold Plated Oval Cable Chain 3mm By The Foot

SKU: CHA-9814

Project uses 2 inches



22K Gold Plated Fish Hook Earring Hooks (50)

SKU: FEA-3020

Project uses 2 pieces



22K Gold Plated 2mm Ball Head Pins 21 Gauge 3 Inches (x20)

SKU: FHP-3023

Project uses 2 pieces



Swarovski Crystal, 5540 Artemis Cone Bead 17mm, 1 Piece, Jet

SKU: SWC-2344

Project uses 2 pieces



Swarovski Crystal, 9001 Rondelle Beads 10x3.7mm, 2 Pieces, Gold Plate With Crystal

SKU: SWC-5186

Project uses 2 pieces



Recommended Tools:

[XTL-5600] Xuron Sharp Flush Cutter Pliers - Wire/Soft Flex, [XTL-5514] Beadsmith Jewelry

Fine Round Nose Micro Pliers, [XTL-5511] Beadsmith Jeweller's Micro Pliers Chain Nose Flat

Nose



Instructions

By following the instructions below, you will make one earring. Repeat all instructions to make the second earring.

1. Using your flush cutters, cut a 1 inch length of Nunn Design antiqued gold plated chain. Set aside.
2. Next, onto a gold plated ball head pin, slide on a black Swarovski artemis cone bead, followed by a Swarovski crystal rondelle bead and another black Swarovski artemis cone bead. Also slide on the last link from one side of your chain length.
3. Create a wrapped-wire loop with your round nose pliers and snip off any excess with your flush cutters.
4. With your chain nose pliers, open the loop on your earring hook (how you would a jump ring) and slide on the last link from the other end of your chain length and close.

5. That's it!