

## Joyful Lemon Necklace

### Project N2257

*Kat Silvia*

A citrus drop of yellow with a touch of Eden Green Swarovski Crystal pearls make for a sweet vintage style necklace.

### What You'll Need

TierraCast Bezel Pendant, Fits #4320 Pear 14x10mm, 1 Piece, Antiqued Brass

SKU: PNT-130

Project uses 1 piece



Swarovski Crystal, #5810 Round Faux Pearl Beads 4mm, 50 Pieces, Eden Green

SKU: SWP-4086

Project uses 3 pieces



Vintaj Natural Brass Cable Chain, 3mm, by the Foot

SKU: CHA-99892

Project uses 18 Inches



Antiqued Brass Head Pins 1 Inch / 22 Gauge (X50)

SKU: FHP-6310

Project uses 3 pieces



Antiqued Brass Sleek Lobster Claw Clasps 10mm (10)

SKU: FCL-2607

Project uses 1 piece



ICE Resin Jewelers Grade Clear Casting Epoxy Resin 8 oz Kit

SKU: TRC-10

Project uses 1 piece



CASTIN CRAFT Casting Epoxy Resin Opaque Yellow Pigment Dye 1 Oz

SKU: TRC-82

Project uses 1 piece



CASTIN CRAFT Casting Epoxy Resin Opaque White Pigment Dye 1 Oz

SKU: TRC-87

Project uses 1 piece



### Recommended Tools:

[TRC-604] ICE Resin, Mixing Cups & White Stir Sticks, 20 Pack, [XTL-5600] Sharp Flush Cutter Pliers - For Cutting Beading Wire, 1 Piece, [XTL-5511] Beadsmith Jeweller's Micro Pliers Chain Nose Flat Nose, [XTL-5514] Beadsmith Jewelry Fine Round Nose Micro Pliers



## Instructions

This necklace measures approximately 18 inches. To modify the length, simply adjust the length of chain on both sides respectively. We also recommend

using museum putty to help keep your pendant level as it cures. You will also need a lighter for this project.

1. Please watch our video: How To Use Ice Resin. From what you learned in the video, mix your resin and separate the amount you want to color into a cup; about 1 tsp. Slowly add two drops of yellow. If you want a lighter color, you can add a little bit of the white at a time.
2. Make sure your pendant is stable and level using the museum putty. Drip the resin into the bezel slowly. Create a slight dome with the resin. Use a lighter to help get rid of any air bubbles. Allow the resin to cure for at least 24 hours.
3. Take one head pin, string on one pearl and make a simple wire loop. Trim any excess wire. Repeat two more times.
4. The chain used in this project has open links that open like jump rings. Remove two links of the chain and set aside. Adjust the length of the chain to suit your style.
5. Find the center of the chain and using one of the opened links, attach it to the pendant and to the center link.
6. Move over two links of chain and take the second open link and attach the three simple wire loops to this link in the chain.
7. Move to the end of the chain, open the jump ring attached to the lobster clasp and attach it to the end link of the chain.