

Jeweled Noir Necklace

Project N3067

Designer: Karlin Jones

Sparkling beautifully, this Swarovski crystal flatback bejeweled necklace is the perfect accessory to glam up your little black

dress.

What You'll Need

Antiqued 22K Gold Plated Round Rolo Chain 3.5mm Bulk By The Foot

<u>ක්ටුප්ටුප්ටුප්ටු</u> SKU: CHA-9666 000000000 Project uses 15 inches 050505050

Czech Fire Polish Glass Beads 12mm x 16mm Teardrop Jet Black (4)

SKU: BCP-5960 Project uses 1 piece

22K Gold Plated Head Pins - 22 Gauge, 2 Inches (X50)

SKU: FHP-5221 Project uses 1 piece



22K Gold Plated Open Jump Rings 8mm 20 Gauge (50)

SKU: FJR-5477 Project uses 9 pieces



22K Gold Plated Open Jump Rings 6mm 18 Gauge (50)

SKU: FJR-5166 Project uses 1 piece



G S Hypo Cement Precise Applicator Essential!

SKU: XTL-1001 Project uses 1 piece



Beautiful Gold Plated Curved Lobster Clasps 10mm (10)

SKU: FCL-2514 Project uses 1 piece



Solid Brass Stamping Blank Curved Rectangle Pendants 19mm x 29mm (2)

SKU: PND-3874 Project uses 6 pieces

Swarovski Crystal, 2058 Flatback Rhinestones Xilion No Hotfix ss16, 50 Pieces, Jet

SKU: SWF-41612 Project uses 32 pieces

Swarovski Crystal, 2058 Flatback Rhinestones Xilion No Hotfix ss20, 50 Pieces, Black Diamond

SKU: SWF-42019 Project uses 30 pieces







Swarovski Crystal, 2058 Flatback Rhinestones Xilion No Hotfix ss9, 72 Pieces, Hematite

SKU: SWF-40915

Project uses 88 pieces

Swarovski Crystal, 2058 Flatback Rhinestones Xilion No Hotfix ss16, 50 Pieces, Jet Hematite

SKU: SWF-41615

Project uses 20 pieces



Recommended Tools:

[XTL-4004] Beadsmith Magical Rhinestone Pick Up Tool With Cleaning Kit - Great For Placing Flatback Rhinestones, [XTL-0061] Eurotool EuroPunch 1.8mm Round Hole Punch Pliers For Bottle Caps, [XTL-5600] Xuron Sharp Flush Cutter Pliers - Wire/Soft Flex, [XTL-5514] Beadsmith Jewelly Fine Round Nose Micro Pliers, [XTL-5511] Beadsmith Jeweller's Micro Pliers Chain Nose Flat Nose

Instructions

To make this necklace longer, simply use a longer length of chain.

- 1. Before you begin, please watch the video on How to Use BeadSmith's Magical Pick Up Tool for Flatback Rhinestones.
- 2. Begin by cutting two 7.5" lengths of gold plated round rolo chain with your flush cutters. Set aside for now.
- 3. Next, take 1 brass stamping and using your Eurotool punch tool, punch a second hole on the opposite side of the hole that is already on the stamping. You will be connecting your stampings using jump rings through these holes, so try and get them as symmetrical as possible. See photo for placement assistance.
- 4. Repeat the process of punching a second hole on all 6 brass stampings.
- 5. Now you will begin adding a selection of Swarovski crystal flat backs onto each stamping using your HypoCement glue. I did not follow any specific patterns, just a mixture of colors: Jet, Black Diamond, Hematite and Jet Hematite. Feel free to add as many or as little of one color as you'd like. Add a dab of glue, use your Magical Pick tool to pick up each flatback and place it down onto the glue. Repeat this process until all your brass stampings are covered. Once done, set all your stampings aside to dry.
- 6. Next, using your chain nose pliers, open a jump ring, slide through the hole from one stamping and the hole from a second stamping and close. You will connect all 6 stampings via jump rings in this manner.
- 7. Once all 6 stampings are connected, open the last jump ring from one end (using your chain nose pliers) and slide on the last link from one end of one length of chain and close. Repeat this step with your second chain length on the other side. See photo.
- 8. Open a jump ring, slide on the loop from your lobster clasp and also the last link from one length of chain and close.
- 9. Open another jump ring and slide it onto the last link from the second length of chain and close.
- 10. Onto a gold plated head pin, slide on one Czech fire polish tear drop bead and create a wrapped wire loop using your round nose pliers. Snip off excess wire using your flush cutters.
- 11. Open a smaller 6mm jump ring, slide on the wrapped wire loop and attach it onto the 4th jump ring at the center of your necklace and close.
- 12. You're done!