Wrapped In Turquoise Necklace

Project N3097

Karlin Jones

Wire wrap pretty turquoise gemstone chips within a modern Nunn Design open framed pendant for a look that is effortlessly boho chic.

What You'll Need

Nunn Design Antiqued Gold Plated Oval Cable Chain 3mm By The Foot

SKU: CHA-9814

Project uses 19 inches

Artistic Wire, Silver Plated Craft Wire 26 Gauge Thick, 15 Yard Spool, Gold Color

SKU: WCR-2632

Project uses 1 spool

Nunn Design Open Frame Pendant, Square 25.5x30.5mm, 1 Piece, Antiqued Gold

SKU: PND-08255

Project uses 1 piece

Gold Plated Curved Lobster Clasps 12mm (10 Pieces)

SKU: FCL-2514

Project uses 1 piece

Blue Green Turquoise Gemstone Beads, 4-9mm Chips, 15 Inch Strand

SKU: SPTU-12

Project uses 28 pieces

22K Gold Plated Open Jump Rings 5mm 20 Gauge (100)

SKU: FJR-5250

Project uses 3 pieces

Recommended Tools:

[XTL-5600] Sharp Flush Cutter Pliers - For Cutting Beading Wire, 1 Piece, [XTL-5511] Beadsmith Jeweller's Micro Pliers Chain Nose Flat Nose

Instructions

This necklaces measures 19" long. For a necklace that is shorter or longer, simply adjust the chain length.

1. Before you begin, please watch the video on How to Wire Wrap Rows of Beads onto a Form. In this wire wrapping video tutorial see how to create neat rows of beads that stretch across a solid form.

2. Following what you learned in the video, cut a length of gold plated wire (you can add on more wire as you go) and wire-wrap a total of 28 turquoise gemstone chips (I added about 10 beads onto each row, but this depends on bead size) onto your Nunn Design open frame pendant. See photo for assistance.

3. Next, using your flush cutters, cut a 19" length of chain.

4. Using your chain nose pliers, open a gold plated jump ring and slide it onto the last link on one side of chain. Close the jump ring.

5. Open another jump ring and attach it onto the last link from the other side of chain. Before closing, also slide on the loop from your gold plated lobster clasp and close.

6. Open a last jump ring, slide on the loop from the top of your pendant and slide it onto chain and close.

7. You're done!