

Kelsey Bracelet

Project B2145

Designer: Kat Silvia

To create a different kind of stretch bracelet, this design uses Rubber O-Rings and Jump Rings in a simple 2-in-2 Chain Maille style weave.

What You'll Need

Rubber O-Ring Jump Ring Spacers 10mm Diameter - Aqua (10)

SKU: FRC-046

Project uses 34 pieces



Artistic Wire Chain Maille Jump Rings Non Tarnish Copper - 18 Ga/ID 5.95mm/100pc

SKU: FMC-1592

Project uses 34 pieces



Recommended Tools:

[XTL-0020] Baby Wubbers Quality Fine Chain Nose Jeweller's Pliers, [XTL-0023] Baby

Wubbers Quality Fine Bent Chain Nose Jeweller's Pliers



Instructions

1. Begin by opening one copper jump ring and linking on four rubber rings. Close the jump ring.
2. Open one more copper jump ring and link it through all four rubber rings so that both copper jump rings lay next to each other. Close the jump ring. You should now be able to spread out the four rubber rings so that you have two on each side of the copper rings. (See Photo)
3. Open one copper jump ring and attach it to two of the rubber rings that are in your strand, and add two more rubber rings. Close the jump ring.
4. Open one more copper jump ring and link it through all four rubber rings so that both copper jump rings lay next to each other. Close the jump ring.
5. Continue in this manner until you have your desired length. Once you have gone all the way around you will simply use two copper jump rings to join both ends for a seamless join.
6. All done!